



Ill. No.	Part No.	DESCRIPTION	Qty.	Change Point	REMARKS
TOOLS					
1	AHH 6540	Bag-tool	1] Except V8 V8
	BHH 1264	Jack-side lift	1		
11	BHA 5178 BHA 5329	Jack-side lift	1	(C)G-HN5-345042 TO 410000 (C)G-HD5-342851 TO 410350 (C)G-D2D1-1424 TO 2903	
3	AHH 6539	Spanner-wheel nut	1] V8. Optional extra. Used when Rostyle wheels are fitted.
10	BHH 1086	Spanner-wheel nut	1	(C)G-HN4-158231 TO 187210	
9	AHH 9153	Spanner	1	(C)G-HN5-187211 TO 410000 (C)G-HD4-158231 TO 187840 (C)G-HD5-187841 TO 410350	
4	31G 957	Lever-hub cap remover	1] Disc wheels.
5	1B 8995	Spanner-box-sparking plug	1		
6	88G 570	Tommy bar-box spanner	1	(C)G-HN4,G-HD4-101 TO 181711] Germany and Switzerland. Wire wheels only.
7	AHH 5839	Spanner-hub cap	1		
8	88G 329	Hammer(copper).....	1		